



RM1589

Fig. 1
Air conditioning circuit

- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Starter motor 2. Battery 3. Ignition switch 4. Terminal post 5. Compressor 6. Fast idle solenoid - Rover 2.3 and Rover 2.6 only 7. Cooling fans 8. Temperature switch 9. Pressure switch - Ranco 10. Pressure switch 11. Starter relay 12. Magnetic clutch relay 13. Cooling fan relay 14. Vacuum solenoid valve 15. Blower motor | <ul style="list-style-type: none"> 16. Blower motor control switch 17. Mode micro switch 18. Operating mode lever <ul style="list-style-type: none"> A Maximum A/C B Normal A/C C Bi-level A/C D Economy vent E Economy vent F Defrost 19. 27 RA Relay assembly 20. Resistor assembly 21. Heated backlight switch 22. Heated backlight relay 23. Heated backlight 24. Heated backlight warning light |
|--|--|

Note: Air conditioning unit controls are shown inside dotted line.